









Installing Battery:

Remove end cap; slide battery cover in direction of arrow [◀] and remove; install one AAA battery; replace battery cover and end cap.

Operating Instructions:

Power ON	Press and hold the Power/Play/Pause button  for 3 seconds. The green light will go on briefly and then turn red for 5-10 seconds while the program loads. Then a steady green light will come on and the BibleStick will begin playing.
Power OFF	Press and hold the  button for 3 seconds; green light will go out and the BibleStick will be "Off"
Pause	Press  button once; green light will blink slowly.
Play	Press  button once; green light will stay on.
Increase Volume	Press and hold  button until desired volume is reached.
Decrease Volume	Press and hold  button until desired volume is reached.
Next File/Book	Press  button once to go to next file. Hold this button to go to the next book.
Previous File/Book	Press  button once to go back to previous file. Hold this button to go back to the previous book.

Features:

- BibleStick will bookmark the exact location when it is on “Pause.” When powered “Off,” BibleStick starts at the beginning of the chapter you were listening to.
- Units on “Pause” will automatically power “Off” after 30 – 35 minutes.
- After the last file is played, the BibleStick will automatically “Pause.”

(Note: Battery is still being used when BibleStick is on “Pause.”)

Low or Dead Battery:

- Red light will blink
 - Volume will decrease
 - BibleStick will turn off when battery is dead
-

To Listen Through Your Computer’s Speakers:

- You can use your computer’s speakers to listen by unplugging the earbuds and plugging external speakers into the BibleStick.

Faith Comes By Hearing / Hosanna
2421 Aztec Road NE / Albuquerque, NM 87107-4200
505.881.3321 or 800.545.6552 / FaithComesByHearing.com